

# Assembly Instructions for *In the Breeze* ATV Ground Spinners

1. Slide Fiberglass Pole (C) into the body of the ATV (A).

2. Screw a Wheel Hub (B) into both the front and back of the ATV. Remove the plastic end caps from the hub and set aside.

3. Slide the wheels onto the hubs and replace the plastic end caps.

**NOTE:** For use in high winds and for extra durability we recommend applying epoxy glue in the end caps.

4. Slide the Ground Stake (W) onto the Fiberglass Pole (C) and tighten the tension screw on the side of the stake to complete assembly.

